



Helios Developer's Guide

0.3.x Kernel

1 Data Structure Index	1
1 Data Structure Index	1
1.1 Data Structures	1
2 File Index	2
2.1 File List	2
3 Data Structure Documentation	2
3.1 QueueMessage_t Struct Reference	2
3.1.1 Detailed Description	2
3.1.2 Field Documentation	3
3.2 SystemInfo_t Struct Reference	3
3.2.1 Detailed Description	3
3.2.2 Field Documentation	4
3.3 TaskInfo_t Struct Reference	4
3.3.1 Detailed Description	5
3.3.2 Field Documentation	5
3.4 TaskNotification_t Struct Reference	6
3.4.1 Detailed Description	6
3.4.2 Field Documentation	6
3.5 TaskRunTimeStats_t Struct Reference	7
3.5.1 Detailed Description	7
3.5.2 Field Documentation	7
4 File Documentation	8
4.1 config.h File Reference	8
4.1.1 Detailed Description	8
4.1.2 Macro Definition Documentation	9
4.2 HeliOS.h File Reference	11
4.2.1 Detailed Description	15
4.2.2 Macro Definition Documentation	16
4.2.3 Typedef Documentation	16
4.2.4 Enumeration Type Documentation	22
4.2.5 Function Documentation	23
Index	45

1 Data Structure Index

1.1 Data Structures

Here are the data structures with brief descriptions:

QueueMessage_t	
Data structure for a message queue message	2

SystemInfo_t	
Data structure for system informaiton	3
TaskInfo_t	
Data structure for information about a task	4
TaskNotification_t	
Data structure for direct to task notifications	6
TaskRunTimeStats_t	
Data structure for task runtime statistics	7

2 File Index

2.1 File List

Here is a list of all documented files with brief descriptions:

config.h	
Kernel header file for user definable settings	8
HeliOS.h	
Header file for end-user application code	11

3 Data Structure Documentation

3.1 QueueMessage_t Struct Reference

Data structure for a message queue message.

```
#include <HeliOS.h>
```

Data Fields

- [Base_t](#) messageBytes
- char [messageValue](#) [[CONFIG_MESSAGE_VALUE_BYTES](#)]

3.1.1 Detailed Description

The [QueueMessage_t](#) data structure contains the message queue message returned by [xQueuePeek\(\)](#) and [xQueueReceive\(\)](#). The [QueueMessage_t](#) type should be declared as [xQueueMessage](#).

See also

[xQueueMessage](#)
[xQueuePeek\(\)](#)
[xQueueReceive\(\)](#)
[xMemFree\(\)](#)
[CONFIG_MESSAGE_VALUE_BYTES](#)

Warning

The memory allocated for an instance of [xQueueMessage](#) must be freed using [xMemFree\(\)](#).

3.1.2 Field Documentation

3.1.2.1 messageBytes `Base_t QueueMessage_t::messageBytes`

The number of bytes in the messageValue member that makes up the message value. This cannot exceed CONFIG_MESSAGE_VALUE_BYTES.

3.1.2.2 messageValue `char QueueMessage_t::messageValue[CONFIG_MESSAGE_VALUE_BYTES]`

the char array that contains the actual message value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

- [HeliOS.h](#)

3.2 SystemInfo_t Struct Reference

Data structure for system information.

```
#include <HeliOS.h>
```

Data Fields

- char [productName](#) [OS_PRODUCT_NAME_SIZE]
- [Base_t majorVersion](#)
- [Base_t minorVersion](#)
- [Base_t patchVersion](#)
- [Base_t numberOfTasks](#)

3.2.1 Detailed Description

The [SystemInfo_t](#) data structure contains information about the HeliOS system and is returned by [xSystemGetSystemInfo\(\)](#). The [SystemInfo_t](#) type should be declared as [xSystemInfo](#).

See also

[xSystemInfo](#)
[xSystemGetSystemInfo\(\)](#)
[xMemFree\(\)](#)

Warning

The memory allocated for an instance of [xSystemInfo](#) must be freed using [xMemFree\(\)](#).

3.2.2 Field Documentation

3.2.2.1 **majorVersion** `Base_t SystemInfo_t::majorVersion`

The major version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

3.2.2.2 **minorVersion** `Base_t SystemInfo_t::minorVersion`

The minor version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

3.2.2.3 **numberOfTasks** `Base_t SystemInfo_t::numberOfTasks`

The number of tasks presently in a suspended, running or waiting state.

3.2.2.4 **patchVersion** `Base_t SystemInfo_t::patchVersion`

The patch version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

3.2.2.5 **productName** `char SystemInfo_t::productName[OS_PRODUCT_NAME_SIZE]`

The name of the operating system or product. Its length is defined by OS_PRODUCT_NAME_SIZE. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

- [HeliOS.h](#)

3.3 TaskInfo_t Struct Reference

Data structure for information about a task.

```
#include <HeliOS.h>
```

Data Fields

- `Base_t id`
- `char name [CONFIG_TASK_NAME_BYTES]`
- `TaskState_t state`
- `Time_t lastRunTime`
- `Time_t totalRunTime`

3.3.1 Detailed Description

The [TaskInfo_t](#) structure is similar to [xTaskRuntimeStats_t](#) in that it contains runtime statistics for a task. However, [TaskInfo_t](#) also contains additional details about a task such as its identifier, ASCII name and state. The [TaskInfo_t](#) structure is returned by [xTaskGetTaskInfo\(\)](#). If only runtime statistics are needed, [TaskRunTimeStats_t](#) should be used because of its lower memory footprint. The [TaskInfo_t](#) type should be declared as [xTaskInfo](#).

See also

- [xTaskInfo](#)
- [xTaskGetTaskInfo\(\)](#)
- [xMemFree\(\)](#)
- [CONFIG_TASK_NAME_BYTES](#)

Warning

The memory allocated for an instance of [xTaskInfo](#) must be freed using [xMemFree\(\)](#).

3.3.2 Field Documentation

3.3.2.1 id [Base_t](#) TaskInfo_t::id

The task identifier which is used by [xTaskGetHandleById\(\)](#) to return the task handle.

3.3.2.2 lastRunTime [Time_t](#) TaskInfo_t::lastRunTime

The runtime duration in microseconds the last time the task was executed by the scheduler.

3.3.2.3 name [char](#) TaskInfo_t::name[[CONFIG_TASK_NAME_BYTES](#)]

The name of the task which is used by [xTaskGetHandleByName\(\)](#) to return the task handle. This is NOT a null terminated string.

3.3.2.4 state [TaskState_t](#) TaskInfo_t::state

The state the task is in which is one of four states specified in the [TaskState_t](#) enumerated data type.

3.3.2.5 totalRunTime [Time_t](#) TaskInfo_t::totalRunTime

The total runtime duration in microseconds the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

- [HeliOS.h](#)

3.4 TaskNotification_t Struct Reference

Data structure for direct to task notifications.

```
#include <Helios.h>
```

Data Fields

- [Base_t notificationBytes](#)
- `char notificationValue [CONFIG_NOTIFICATION_VALUE_BYTES]`

3.4.1 Detailed Description

The [TaskNotification_t](#) data structure contains the direct to task notification returned by [xTaskNotifyTake\(\)](#). The [TaskNotification_t](#) type should be declared as `xTaskNotification`.

See also

[xTaskNotification](#)
[xTaskNotifyTake\(\)](#)
[xMemFree\(\)](#)
[CONFIG_NOTIFICATION_VALUE_BYTES](#)

Warning

The memory allocated for an instance of `xTaskNotification` must be freed using [xMemFree\(\)](#).

3.4.2 Field Documentation

3.4.2.1 notificationBytes `Base_t TaskNotification_t::notificationBytes`

The number of bytes in the `notificationValue` member that makes up the notification value. This cannot exceed `CONFIG_NOTIFICATION_VALUE_BYTES`.

3.4.2.2 notificationValue `char TaskNotification_t::notificationValue[CONFIG_NOTIFICATION_VALUE_BYTES]`

The `char` array that contains the actual notification value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

- [Helios.h](#)

3.5 TaskRunTimeStats_t Struct Reference

Data structure for task runtime statistics.

```
#include <Helios.h>
```

Data Fields

- [Base_t id](#)
- [Time_t lastRunTime](#)
- [Time_t totalRunTime](#)

3.5.1 Detailed Description

The [TaskRunTimeStats_t](#) structure contains task runtime statistics and is returned by [xTaskGetAllRunTimeStats\(\)](#) and [xTaskGetTaskRunTimeStats\(\)](#). The [TaskRunTimeStats_t](#) type should be declared as `xTaskRunTimeStats`.

See also

[xTaskRunTimeStats](#)
[xTaskGetTaskRunTimeStats\(\)](#)
[xTaskGetAllRunTimeStats\(\)](#)
[xMemFree\(\)](#)

Warning

The memory allocated for an instance of `xTaskRunTimeStats` must be freed using [xMemFree\(\)](#).

3.5.2 Field Documentation

3.5.2.1 id [Base_t](#) TaskRunTimeStats_t::id

The task identifier which is used by [xTaskGetHandleById\(\)](#) to return the task handle.

3.5.2.2 lastRunTime [Time_t](#) TaskRunTimeStats_t::lastRunTime

The runtime duration in microseconds the last time the task was executed by the scheduler.

3.5.2.3 totalRunTime [Time_t](#) TaskRunTimeStats_t::totalRunTime

The total runtime duration in microseconds the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

- [Helios.h](#)

4 File Documentation

4.1 config.h File Reference

Kernel header file for user definable settings.

Macros

- #define `CONFIG_ENABLE_ARDUINO_CPP_INTERFACE`
Define to enable the Arduino API C++ interface.
- #define `CONFIG_ENABLE_SYSTEM_ASSERT`
Define to enable system assertions.
- #define `CONFIG_SYSTEM_ASSERT_BEHAVIOR`(f, l) `ArduinoAssert(f , l)`
Define the system assertion behavior.
- #define `CONFIG_MESSAGE_VALUE_BYTES` 8u
Define the size in bytes of the message queue message value.
- #define `CONFIG_NOTIFICATION_VALUE_BYTES` 8u
Define the size in bytes of the direct to task notification value.
- #define `CONFIG_TASK_NAME_BYTES` 8u
Define the size in bytes of the ASCII task name.
- #define `CONFIG_HEAP_SIZE_IN_BLOCKS` 512u
Define the number of blocks in the heap.
- #define `CONFIG_HEAP_BLOCK_SIZE` 32u
Define the heap block size in bytes.
- #define `CONFIG_QUEUE_MINIMUM_LIMIT` 5u
Define the minimum value for a message queue limit.

4.1.1 Detailed Description

Author

Manny Peterson (mannymsp@gmail.com)

Version

0.3.1

Date

2022-01-31

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <https://www.gnu.org/licenses/>.

4.1.2 Macro Definition Documentation

4.1.2.1 CONFIG_ENABLE_ARDUINO_CPP_INTERFACE `#define CONFIG_ENABLE_ARDUINO_CPP_INTERFACE`

Because HeliOS kernel is written in C, the Arduino API cannot be called directly from the kernel. For example, assertions are unable to be written to the serial bus in applications using the Arduino platform/tool-chain. The `CONFIG_ENABLE_ARDUINO_CPP_INTERFACE` builds the included `arduino.cpp` file to allow the kernel to call the Arduino API through wrapper functions such as `ArduinoAssert()`. The `arduino.cpp` file can be found in the `/extras` directory. It must be copied into the `/src` directory to be built.

Note

Neither this setting nor the `arduino.cpp` file are needed if the end-user does not plan to use assertions on the Arduino platform/tool-chain.

4.1.2.2 CONFIG_ENABLE_SYSTEM_ASSERT `#define CONFIG_ENABLE_SYSTEM_ASSERT`

The `CONFIG_ENABLE_SYSTEM_ASSERT` setting allows the end-user to enable system assertions in HeliOS. Once enabled, the end-user must define `CONFIG_SYSTEM_ASSERT_BEHAVIOR` for there to be an effect. By default the `CONFIG_ENABLE_SYSTEM_ASSERT` setting is not defined.

See also

[CONFIG_SYSTEM_ASSERT_BEHAVIOR](#)

4.1.2.3 CONFIG_HEAP_BLOCK_SIZE `#define CONFIG_HEAP_BLOCK_SIZE 32u`

Setting `CONFIG_HEAP_BLOCK_SIZE` allows the end-user to define the size of a heap block in bytes. The block size should be set to achieve the best possible utilization of the heap. A block size that is too large will waste the heap for smaller requests for heap. A block size that is too small will waste heap on entries. The default value is 32 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xMemAlloc\(\)](#)

[xMemFree\(\)](#)

[CONFIG_HEAP_SIZE_IN_BLOCKS](#)

4.1.2.4 **CONFIG_HEAP_SIZE_IN_BLOCKS** `#define CONFIG_HEAP_SIZE_IN_BLOCKS 512u`

Setting `CONFIG_HEAP_SIZE_IN_BLOCKS` allows the end-user to define the size of the heap in blocks. The size of a block in the heap is determined by the `CONFIG_HEAP_BLOCK_SIZE` which is represented in bytes. The size of the heap needs to be adjusted to fit the memory requirements of the end-user's application. By default the `CONFIG_HEAP_SIZE_IN_BLOCKS` setting is not defined. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xMemAlloc\(\)](#)
[xMemFree\(\)](#)
[CONFIG_HEAP_BLOCK_SIZE](#)

Note

To use the platform and/or tool-chain defaults, leave `CONFIG_HEAP_SIZE_IN_BLOCKS` undefined.

4.1.2.5 **CONFIG_MESSAGE_VALUE_BYTES** `#define CONFIG_MESSAGE_VALUE_BYTES 8u`

Setting the `CONFIG_MESSAGE_VALUE_BYTES` allows the end-user to define the size of the message queue message value. The larger the size of the message value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xQueueMessage](#)

4.1.2.6 **CONFIG_NOTIFICATION_VALUE_BYTES** `#define CONFIG_NOTIFICATION_VALUE_BYTES 8u`

Setting the `CONFIG_NOTIFICATION_VALUE_BYTES` allows the end-user to define the size of the direct to task notification value. The larger the size of the notification value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xTaskNotification](#)

4.1.2.7 CONFIG_QUEUE_MINIMUM_LIMIT `#define CONFIG_QUEUE_MINIMUM_LIMIT 5u`

Setting the CONFIG_QUEUE_MINIMUM_LIMIT allows the end-user to define the MINIMUM length limit a message queue can be created with [xQueueCreate\(\)](#). When a message queue length equals its limit, the message queue will be considered full and return true when [xQueuelQueueFull\(\)](#) is called. A full queue will also not accept messages from [xQueueSend\(\)](#). The default value is 5. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xQueuelQueueFull\(\)](#)
[xQueueSend\(\)](#)
[xQueueCreate\(\)](#)

4.1.2.8 CONFIG_SYSTEM_ASSERT_BEHAVIOR `#define CONFIG_SYSTEM_ASSERT_BEHAVIOR(f, l) ArduinoAssert(f , l)`

The CONFIG_SYSTEM_ASSERT_BEHAVIOR setting allows the end-user to specify the behavior (code) of the assertion which is called when CONFIG_ENABLE_SYSTEM_ASSERT is defined. Typically some sort of output is generated over a serial or other interface. By default the CONFIG_SYSTEM_ASSERT_BEHAVIOR is not defined.

Note

In order to use the ArduinoAssert() functionality, the CONFIG_ENABLE_ARDUINO_CPP_INTERFACE setting must be enabled.

See also

[CONFIG_ENABLE_SYSTEM_ASSERT](#)
[CONFIG_ENABLE_ARDUINO_CPP_INTERFACE](#)

```
#define CONFIG_SYSTEM_ASSERT_BEHAVIOR(f, l) ArduinoAssert( f , l )
```

4.1.2.9 CONFIG_TASK_NAME_BYTES `#define CONFIG_TASK_NAME_BYTES 8u`

Setting the CONFIG_TASK_NAME_BYTES allows the end-user to define the size of the ASCII task name. The larger the size of the task name, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

[xTaskInfo](#)

4.2 HeliOS.h File Reference

Header file for end-user application code.

Data Structures

- struct [TaskRunTimeStats_t](#)
Data structure for task runtime statistics.
- struct [TaskInfo_t](#)
Data structure for information about a task.
- struct [TaskNotification_t](#)
Data structure for direct to task notifications.
- struct [QueueMessage_t](#)
Data structure for a message queue message.
- struct [SystemInfo_t](#)
Data structure for system information.

Macros

- `#define DEREF_TASKPARAM(t, p) *((t *)p)`
A C macro to simplify casting and dereferencing a task parameter.

Typedefs

- typedef uint8_t [Base_t](#)
Type definition for the base data type.
- typedef TIME_T_TYPE [Time_t](#)
Type definition for system time measured in microseconds.
- typedef void [Task_t](#)
Stub type definition for the task type.
- typedef void [TaskParm_t](#)
Type definition for the task parameter.
- typedef void [Queue_t](#)
Stub type definition for the message queue type.
- typedef void [Timer_t](#)
Stub type definition for the timer type.
- typedef [Base_t](#) xBase
Type definition for the base data type.
- typedef [Timer_t](#) * xTimer
Stub type definition for the timer type.
- typedef [Queue_t](#) * xQueue
Stub type definition for the message queue type.
- typedef [QueueMessage_t](#) * xQueueMessage
Data structure for a message queue message.
- typedef [TaskNotification_t](#) * xTaskNotification
Data structure for direct to task notifications.
- typedef [TaskInfo_t](#) * xTaskInfo
Data structure for information about a task.
- typedef [TaskRunTimeStats_t](#) * xTaskRunTimeStats
Data structure for task runtime statistics.
- typedef [Task_t](#) * xTask
Stub type definition for the task type.
- typedef [TaskParm_t](#) * xTaskParm
Type definition for the task parameter.

- typedef [Time_t](#) [xTime](#)
The type definition for time expressed in microseconds.
- typedef [TaskState_t](#) [xTaskState](#)
Enumerated type for task states.
- typedef [SchedulerState_t](#) [xSchedulerState](#)
Enumerated type for scheduler states.
- typedef [SystemInfo_t](#) * [xSystemInfo](#)
Data structure for system information.

Enumerations

- enum [TaskState_t](#) { [TaskStateError](#) , [TaskStateSuspended](#) , [TaskStateRunning](#) , [TaskStateWaiting](#) }
Enumerated type for task states.
- enum [SchedulerState_t](#) { [SchedulerStateError](#) , [SchedulerStateSuspended](#) , [SchedulerStateRunning](#) }
Enumerated type for scheduler states.

Functions

- void [SystemAssert](#) (const char *file_, int line_)
System call to handle assertions.
- void * [xMemAlloc](#) (size_t size_)
System call to allocate memory from the heap.
- void [xMemFree](#) (void *ptr_)
System call to free memory allocated from the heap.
- size_t [xMemGetUsed](#) (void)
System call to return the amount of allocated heap memory.
- size_t [xMemGetSize](#) (void *ptr_)
System call to return the amount of heap memory allocated for a pointer.
- [xQueue](#) [xQueueCreate](#) ([xBase](#) limit_)
System call to create a new message queue.
- void [xQueueDelete](#) ([xQueue](#) queue_)
System call to delete a message queue.
- [xBase](#) [xQueueGetLength](#) ([xQueue](#) queue_)
System call to get the length of the message queue.
- [xBase](#) [xQueueIsQueueEmpty](#) ([xQueue](#) queue_)
System call to check if the message queue is empty.
- [xBase](#) [xQueueIsQueueFull](#) ([xQueue](#) queue_)
System call to check if the message queue is full.
- [xBase](#) [xQueueMessagesWaiting](#) ([xQueue](#) queue_)
System call to check if there are message queue messages waiting.
- [xBase](#) [xQueueSend](#) ([xQueue](#) queue_, [xBase](#) messageBytes_, const char *messageValue_)
System call to send a message using a message queue.
- [xQueueMessage](#) [xQueuePeek](#) ([xQueue](#) queue_)
System call to peek at the next message in a message queue.
- void [xQueueDropMessage](#) ([xQueue](#) queue_)
System call to drop the next message in a message queue.
- [xQueueMessage](#) [xQueueReceive](#) ([xQueue](#) queue_)
System call to receive the next message in the message queue.
- void [xTaskStartScheduler](#) (void)

- System call to pass control to the HeliOS scheduler.*

 - void `xTaskResumeAll` (void)
- System call to set scheduler state to running.*

 - void `xTaskSuspendAll` (void)
- System call to set the scheduler state to suspended.*

 - `xSystemInfo` `xSystemGetSystemInfo` (void)

The `xSystemGetSystemInfo()` system call will return the type `xSystemInfo` containing information about the system including the OS (product) name, its version and how many tasks are currently in the running, suspended or waiting states.
- `xTask` `xTaskCreate` (const char *name_, void(*callback_)(xTask, xTaskParm), xTaskParm taskParameter_)

System call to create a new task.
- void `xTaskDelete` (xTask task_)

System call to delete a task.
- `xTask` `xTaskGetHandleByName` (const char *name_)

System call to get a task's handle by its ASCII name.
- `xTask` `xTaskGetHandleById` (xBase id_)

System call to get a task's handle by its task identifier.
- `xTaskRunTimeStats` `xTaskGetAllRunTimeStats` (xBase *tasks_)

System call to return task runtime statistics for all tasks.
- `xTaskRunTimeStats` `xTaskGetTaskRunTimeStats` (xTask task_)

System call to return task runtime statistics for the specified task.
- `xBase` `xTaskGetNumberOfTasks` (void)

System call to return the number of tasks regardless of their state.
- `xTaskInfo` `xTaskGetTaskInfo` (xTask task_)

System call to return the details of a task.
- `xTaskInfo` * `xTaskGetAllTaskInfo` (xBase *tasks_)

System call to return the details of all tasks.
- `xTaskState` `xTaskGetTaskState` (xTask task_)

System call to return the state of a task.
- char * `xTaskGetName` (xTask task_)

System call to return the ASCII name of a task.
- `xBase` `xTaskGetId` (xTask task_)

System call to return the task identifier for a task.
- void `xTaskNotifyStateClear` (xTask task_)

System call to clear a waiting direct to task notification.
- `xBase` `xTaskNotificationIsWaiting` (xTask task_)

System call to check if a direct to task notification is waiting.
- `Base_t` `xTaskNotifyGive` (xTask task_, xBase notificationBytes_, const char *notificationValue_)

System call to give another task a direct to task notification.
- `xTaskNotification` `xTaskNotifyTake` (xTask task_)

System call to take a direct to task notification from another task.
- void `xTaskResume` (xTask task_)

System call to resume a task.
- void `xTaskSuspend` (xTask task_)

System call to suspend a task.
- void `xTaskWait` (xTask task_)

System call to place a task in a waiting state.
- void `xTaskChangePeriod` (xTask task_, xTime timerPeriod_)

System call to set the task timer period.
- `xTime` `xTaskGetPeriod` (xTask task_)

System call to get the task timer period.

- void `xTaskResetTimer` (`xTask` task_)
System call to reset the task timer.
- `xSchedulerState` `xTaskGetSchedulerState` (void)
System call to get the state of the scheduler.
- `xTimer` `xTimerCreate` (`xTime` timerPeriod_)
System call to create a new timer.
- void `xTimerDelete` (`xTimer` timer_)
System call will delete a timer.
- void `xTimerChangePeriod` (`xTimer` timer_, `xTime` timerPeriod_)
System call to change the period of a timer.
- `xTime` `xTimerGetPeriod` (`xTimer` timer_)
System call to get the period of a timer.
- `xBase` `xTimerIsTimerActive` (`xTimer` timer_)
System call to check if a timer is active.
- `xBase` `xTimerHasTimerExpired` (`xTimer` timer_)
System call to check if a timer has expired.
- void `xTimerReset` (`xTimer` timer_)
System call to reset a timer.
- void `xTimerStart` (`xTimer` timer_)
System call to start a timer.
- void `xTimerStop` (`xTimer` timer_)
The `xTimerStop()` system call will place the timer in the stopped state. Neither `xTimerStart()` nor `xTimerStop()` will reset the timer. Timers can only be reset with `xTimerReset()`.
- void `xSystemHalt` (void)
The `xSystemHalt()` system call will halt HeliOS.

4.2.1 Detailed Description

Author

Manny Peterson (mannymsp@gmail.com)

Version

0.3.1

Date

2022-01-31

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <https://www.gnu.org/licenses/>.

4.2.2 Macro Definition Documentation

4.2.2.1 Deref_TaskParm `#define Deref_TaskParm(
 t,
 p) *((t *)p)`

When a task parameter is passed to a task, it is passed as a pointer of type void. To use the parameter, it must first be cast to the correct type and dereferenced. The following is an example of how the [Deref_TaskParm\(\)](#) C macro simplifies that process.

```
void myTask_main(xTask task_, xTaskParm parm_) {  
    int i;  
    i = Deref_TaskParm(int, parm_);  
    i++;  
    Deref_TaskParm(int, parm_) = i;  
    return;  
}
```

Parameters

<i>t</i>	The data type to cast the task parameter to (e.g., int).
<i>p</i>	The task pointer, often named parm_.

4.2.3 Typedef Documentation

4.2.3.1 Base_t `typedef uint8_t Base_t`

A simple data type is often needed as an argument for a system call or a return type. The Base_t type is used in such a case where there are no other structural data requirements and is typically an unsigned 8-bit integer. The Base_t type should be declared as xBase.

See also

[xBase](#)

4.2.3.2 Queue_t `typedef void Queue_t`

The Queue_t type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible. The Queue_t type should be declared as xQueue.

See also

[xQueue](#)

[xQueueDelete\(\)](#)

Warning

The memory allocated for an instance of xQueue must be freed using [xQueueDelete\(\)](#).

4.2.3.3 Task_t typedef void Task_t

The Task_t type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible. The Task_t type should be declared as xTask.

See also

[xTask](#)
[xTaskDelete\(\)](#)

Warning

The memory allocated for an instance of xTask must be freed by [xTaskDelete\(\)](#)

4.2.3.4 TaskParm_t typedef void TaskParm_t

The TaskParm_t type is used to pass a parameter to a task at the time of creation using [xTaskCreate\(\)](#). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up to the end-user to manage, allocate and free the memory related to these objects using [xMemAlloc\(\)](#) and [xMemFree\(\)](#). The TaskParm_t should be declared as xTaskParm.

See also

[xTaskParm](#)
[xMemAlloc\(\)](#)
[xMemFree\(\)](#)

Warning

The memory allocated for an instance of xTaskParm must be freed using [xMemFree\(\)](#).

4.2.3.5 Time_t typedef TIME_T_TYPE Time_t

The type definition for time expressed in microseconds.

The Time_t type is used to store system time which is measured in microseconds from system initialization. Despite its name, this type does not store real time clock (RTC) time or date information.

The xTime type is used by several of the task and timer related system calls to express time. The unit of measure for time is always microseconds.

4.2.3.6 **Timer_t** `typedef void Timer_t`

The `Timer_t` type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible. The `Timer_t` type should be declared as `xTimer`.

See also

[xTimer](#)
[xTimerDelete\(\)](#)

Warning

The memory allocated for an instance of `xTimer` must be freed using [xTimerDelete\(\)](#).

4.2.3.7 **xBase** `typedef Base_t xBase`

A simple data type is often needed as an argument for a system call or a return type. The `xBase` type is used in such a case where there are no other structural data requirements is typically an unsigned 8-bit integer.

See also

[Base_t](#)

4.2.3.8 **xQueue** `typedef Queue_t* xQueue`

The `xQueue` type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible.

See also

[Queue_t](#)
[xQueueDelete\(\)](#)

Warning

The memory allocated for an instance of `xQueue` must be freed using [xQueueDelete\(\)](#).

4.2.3.9 xQueueMessage `typedef QueueMessage_t* xQueueMessage`

The xQueueMessage data structure contains the message queue message returned by [xQueuePeek\(\)](#) and [xQueueReceive\(\)](#). See [QueueMessage_t](#) for information about the data structure's members.

See also

[QueueMessage_t](#)
[xQueuePeek\(\)](#)
[xQueueReceive\(\)](#)
[xMemFree\(\)](#)
[CONFIG_MESSAGE_VALUE_BYTES](#)

Warning

The memory allocated for an instance of xQueueMessage must be freed using [xMemFree\(\)](#).

4.2.3.10 xSchedulerState `typedef SchedulerState_t xSchedulerState`

The scheduler can be in one of four possible states defined in the SchedulerState_t enumerated type. The state of the scheduler is changed by calling [xTaskSuspendAll\(\)](#) and [xTaskResumeAll\(\)](#). The state can be obtained by calling [xTaskGetSchedulerState\(\)](#).

See also

[xSchedulerState](#)
[xTaskSuspendAll\(\)](#)
[xTaskResumeAll\(\)](#)
[xTaskGetSchedulerState\(\)](#)

4.2.3.11 xSystemInfo `typedef SystemInfo_t* xSystemInfo`

The xSystemInfo data structure contains information about the HeliOS system and is returned by [xSystemGetSystemInfo\(\)](#). See [xSystemInfo_t](#) for information about the data structure's members.

See also

[SystemInfo_t](#)
[xSystemGetSystemInfo\(\)](#)
[xMemFree\(\)](#)

Warning

The memory allocated for an instance of xSystemInfo must be freed using [xMemFree\(\)](#).

4.2.3.12 **xTask** `typedef Task_t* xTask`

The xTask type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible.

See also

[Task_t](#)
[xTaskCreate\(\)](#)
[xTaskDelete\(\)](#)

Warning

The memory allocated for an instance of xTask must be freed by [xTaskDelete\(\)](#)

4.2.3.13 **xTaskInfo** `typedef TaskInfo_t* xTaskInfo`

The xTaskInfo structure is similar to xTaskRunTimeStats in that it contains runtime statistics for a task. However, xTaskInfo also contains additional details about a task such as its identifier, ASCII name and state. The xTaskInfo structure is returned by [xTaskGetTaskInfo\(\)](#). If only runtime statistics are needed, xTaskRunTimeStats should be used because of its lower memory footprint. See [TaskInfo_t](#) for information about the data structure's members.

See also

[TaskInfo_t](#)
[xTaskGetTaskInfo\(\)](#)
[xMemFree\(\)](#)
[CONFIG_TASK_NAME_BYTES](#)

Warning

The memory allocated for an instance of xTaskInfo must be freed using [xMemFree\(\)](#).

4.2.3.14 **xTaskNotification** `typedef TaskNotification_t* xTaskNotification`

The xTaskNotification data structure contains the direct to task notification returned by [xTaskNotifyTake\(\)](#). See [TaskNotification_t](#) for information about the data structure's members.

See also

[TaskNotification_t](#)
[xTaskNotifyTake\(\)](#)
[xMemFree\(\)](#)
[CONFIG_NOTIFICATION_VALUE_BYTES](#)

Warning

The memory allocated for an instance of xTaskNotification must be freed using [xMemFree\(\)](#).

4.2.3.15 xTaskParm `typedef TaskParm_t* xTaskParm`

The xTaskParm type is used to pass a parameter to a task at the time of creation using [xTaskCreate\(\)](#). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up to the end-user to manage allocate and free the memory related to these objects using [xMemAlloc\(\)](#) and [xMemFree\(\)](#).

See also

[TaskParm_t](#)

[xMemAlloc\(\)](#)

[xMemFree\(\)](#)

Warning

The memory allocated for an instance of xTaskParm must be freed using [xMemFree\(\)](#).

4.2.3.16 xTaskRunTimeStats `typedef TaskRunTimeStats_t* xTaskRunTimeStats`

The xTaskRunTimeStats structure contains task runtime statistics and is returned by [xTaskGetAllRunTimeStats\(\)](#) and [xTaskGetTaskRunTimeStats\(\)](#). See [TaskRunTimeStats_t](#) for information about the data structure's members.

See also

[TaskRunTimeStats_t](#)

[xTaskGetTaskRunTimeStats\(\)](#)

[xTaskGetAllRunTimeStats\(\)](#)

[xMemFree\(\)](#)

Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using [xMemFree\(\)](#).

4.2.3.17 xTaskState `typedef TaskState_t xTaskState`

A task can be in one of the four possible states defined in the TaskState_t enumerated type. The state of a task is changed by calling [xTaskResume\(\)](#), [xTaskSuspend\(\)](#) or [xTaskWait\(\)](#).

See also

[TaskState_t](#)

[xTaskResume\(\)](#)

[xTaskSuspend\(\)](#)

[xTaskWait\(\)](#)

4.2.3.18 xTime `typedef Time_t xTime`

The xTime type is used by several of the task and timer related system calls to express time. The unit of measure for time is always microseconds.

See also

[Time_t](#)

4.2.3.19 xTimer `typedef Timer_t* xTimer`

The xTimer type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible.

See also

[Timer_t](#)

[xTimerDelete\(\)](#)

Warning

The memory allocated for an instance of xTimer must be freed using [xTimerDelete\(\)](#).

4.2.4 Enumeration Type Documentation**4.2.4.1 SchedulerState_t** `enum SchedulerState_t`

The scheduler can be in one of four possible states defined in the SchedulerState_t enumerated type. The state of the scheduler is changed by calling [xTaskSuspendAll\(\)](#) and [xTaskResumeAll\(\)](#). The state can be obtained by calling [xTaskGetSchedulerState\(\)](#).

See also

[xSchedulerState](#)

[xTaskSuspendAll\(\)](#)

[xTaskResumeAll\(\)](#)

Enumerator

SchedulerStateError	Not used.
SchedulerStateSuspended	State the scheduler is in after xTaskSuspendAll() is called.
SchedulerStateRunning	State the scheduler is in after xTaskResumeAll() is called.

4.2.4.2 TaskState_t `enum TaskState_t`

A task can be in one of the four possible states defined in the TaskState_t enumerated type. The state of a task is changed by calling [xTaskResume\(\)](#), [xTaskSuspend\(\)](#) or [xTaskWait\(\)](#). The TaskState_t enumerated type should be declared as xTaskState.

See also

[xTaskState](#)
[xTaskResume\(\)](#)
[xTaskSuspend\(\)](#)
[xTaskWait\(\)](#)

Enumerator

TaskStateError	Returned by xTaskGetTaskState() when task cannot be found.
TaskStateSuspended	State a task is in when it is first created by xTaskCreate() or suspended by xTaskSuspend() .
TaskStateRunning	State a task is in after xTaskResume() is called.
TaskStateWaiting	State a task is in after xTaskWait() is called.

4.2.5 Function Documentation**4.2.5.1 SystemAssert()** `void SystemAssert (`

```

    const char * file_,
    int line_ )

```

The [SystemAssert\(\)](#) system call handles assertions. The [SystemAssert\(\)](#) system call should not be called directly. Instead, the SYSASSERT() macro should be used. The system assertion functionality will only work when the CONFIG_ENABLE_SYSTEM_ASSERT and CONFIG_SYSTEM_ASSERT_BEHAVIOR settings are defined.

See also

SYSASSERT
[CONFIG_ENABLE_SYSTEM_ASSERT](#)
[CONFIG_SYSTEM_ASSERT_BEHAVIOR](#)

Parameters

<i>file</i> ↔ —	This is automatically defined by the compiler's definition of <i>FILE</i>
<i>line</i> ↔ —	This is automatically defined by the compiler's definition of <i>LINE</i>

4.2.5.2 xMemAlloc() `void * xMemAlloc (`
`size_t size_)`

The [xMemAlloc\(\)](#) system call allocates memory from the heap for HeliOS system calls and end-user tasks. The size of the heap, in bytes, is dependent on the `CONFIG_HEAP_SIZE_IN_BLOCKS` and `CONFIG_HEAP_BLOCK_SIZE` settings. [xMemAlloc\(\)](#) functions similarly to `calloc()` in that it clears the memory it allocates.

See also

[CONFIG_HEAP_SIZE_IN_BLOCKS](#)
[CONFIG_HEAP_BLOCK_SIZE](#)
[xMemFree\(\)](#)

Parameters

<code>size_↔</code> —	The amount (size) of the memory to be allocated from the heap in bytes.
--------------------------	---

Returns

`void*` If successful, [xMemAlloc\(\)](#) returns a pointer to the newly allocated memory. If unsuccessful, the system call will return null.

Note

HeliOS technically does not allocate memory from what is traditionally heap memory. HeliOS uses a private "heap" which is actually static memory allocated at compile time. This is done to maintain MISRA C:2012 compliance since standard library functions like `malloc()`, `calloc()` and `free()` are not permitted.

4.2.5.3 xMemFree() `void xMemFree (`
`void * ptr_)`

The [xMemFree\(\)](#) system call will free heap memory allocated by [xMemAlloc\(\)](#) and other HeliOS system calls such as [xSystemGetSystemInfo\(\)](#).

See also

[xMemAlloc\(\)](#)

Parameters

<code>ptr_↔</code> —	The pointer to the allocated heap memory to be freed.
-------------------------	---

Warning

[xMemFree\(\)](#) cannot be used to free memory allocated for kernel objects. Memory allocated by [xTaskCreate\(\)](#), [xTimerCreate\(\)](#) or [xQueueCreate\(\)](#) must be freed by their respective delete system calls (i.e., [xTaskDelete\(\)](#)).

4.2.5.4 xMemGetSize() `size_t xMemGetSize (`
`void * ptr_)`

The `xMemGetSize()` system call returns the amount of heap memory in bytes that is currently allocated to a specific pointer. If the pointer is null or invalid, `xMemGetSize()` will return zero bytes.

Parameters

<code>ptr_</code>	The pointer to the allocated heap memory to obtain the size of the memory, in bytes, that is allocated.
—	

Returns

`size_t` The amount of memory currently allocated to the specific pointer in bytes. If the pointer is invalid or null, `xMemGetSize()` will return zero.

Note

If the pointer `ptr_` points to a structure that, for example, is 48 bytes in size base on `sizeof()`, `xMemGetSize()` will return the number of bytes allocated by the block(s) that contain the structure. Assuming the default block size of 32, a 48 byte structure would require TWO blocks so `xMemGetSize()` would return 64 - not 48. `xMemGetSize()` also checks the health of the heap and will return zero if it detects a consistency issue with the heap. Thus, `xMemGetSize()` can be used to validate pointers before the objects they reference are accessed.

4.2.5.5 xMemGetUsed() `size_t xMemGetUsed (`
`void)`

The `xMemGetUsed()` system call returns the amount of heap memory, in bytes, that is currently allocated. Calls to `xMemAlloc()` increases and `xMemFree()` decreases the amount of memory in use.

Returns

`size_t` The amount of memory currently allocated in bytes. If no heap memory is currently allocated, `xMemGetUsed()` will return zero.

Note

`xMemGetUsed()` returns the amount of heap memory that is currently allocated to end-user objects AND kernel objects. However, only end-user objects may be freed using `xMemFree()`. Kernel objects must be freed using their respective delete system call (e.g., `xTaskDelete()`).

4.2.5.6 xQueueCreate() `xQueue xQueueCreate (`
`xBase limit_)`

The `xQueueCreate()` system call creates a message queue for inter-task communication.

See also

`xQueue`
`xQueueDelete()`
`CONFIG_QUEUE_MINIMUM_LIMIT`

Parameters

<i>limit</i> ↔ —	The message limit for the queue. When this number is reach, the queue is considered full and xQueueSend() will fail. The minimum limit for queues is dependent on the setting CONFIG_QUEUE_MINIMUM_LIMIT.
---------------------	---

Returns

xQueue A queue is returned if successful, otherwise null is returned if unsuccessful.

Warning

The message queue memory can only be freed by [xQueueDelete\(\)](#).

4.2.5.7 xQueueDelete() `void xQueueDelete (`
`xQueue queue_)`

The [xQueueDelete\(\)](#) system call will delete a message queue created by [xQueueCreate\(\)](#). [xQueueDelete\(\)](#) will delete a queue regardless of how many messages the queue contains at the time [xQueueDelete\(\)](#) is called. Any messages the message queue contains will be deleted in the process of deleting the message queue.

See also

[xQueueCreate\(\)](#)

Parameters

<i>queue</i> ↔ —	The queue to be deleted.
---------------------	--------------------------

4.2.5.8 xQueueDropMessage() `void xQueueDropMessage (`
`xQueue queue_)`

The [xQueueDropMessage\(\)](#) system call will drop the next message from the message queue without returning the message.

Parameters

<i>queue</i> ↔ —	The queue to drop the next message from.
---------------------	--

4.2.5.9 xQueueGetLength() `xBase` `xQueueGetLength (`
`xQueue queue_)`

The `xQueueGetLength()` system call returns the length of the queue (the number of messages the queue currently contains).

Parameters

<code>queue</code> ↔	The queue to return the length of.
—	

Returns

`xBase` The number of messages in the queue. If unsuccessful or if the queue is empty, `xQueueGetLength()` returns zero.

4.2.5.10 `xQueueIsQueueEmpty()` `xBase` `xQueueIsQueueEmpty` (`xQueue` `queue_`)

The `xQueueIsQueueEmpty()` system call will return a true or false dependent on whether the queue is empty (message queue length is zero) or contains one or more messages.

Parameters

<code>queue</code> ↔	The queue to determine whether it is empty.
—	

Returns

`xBase` True if the queue is empty. False if the queue has one or more messages. `xQueueIsQueueEmpty()` will also return false if the queue parameter is invalid.

4.2.5.11 `xQueueIsQueueFull()` `xBase` `xQueueIsQueueFull` (`xQueue` `queue_`)

The `xQueueIsQueueFull()` system call will return a true or false dependent on whether the queue is full or contains zero messages. A queue is considered full if the number of messages in the queue is equal to the queue's length limit.

Parameters

<code>queue</code> ↔	The queue to determine whether it is full.
—	

Returns

`xBase` True if the queue is full. False if the queue has zero. `xQueueIsQueueFull()` will also return false if the queue parameter is invalid.

4.2.5.12 xQueueMessagesWaiting() `xBase xQueueMessagesWaiting (` `xQueue queue_)`

The `xQueueMessagesWaiting()` system call returns true or false dependent on whether there is at least one message waiting. The message queue does not have to be full to return true.

Parameters

<code>queue↔</code>	The queue to determine whether one or more messages are waiting.
—	

Returns

`xBase` True if one or more messages are waiting. False if there are no messages waiting of the queue parameter is invalid.

4.2.5.13 xQueuePeek() `xQueueMessage xQueuePeek (` `xQueue queue_)`

The `xQueuePeek()` system call will return the next message in the specified message queue without dropping the message.

See also

[xQueueMessage](#)
[xMemFree\(\)](#)

Parameters

<code>queue↔</code>	The queue to return the next message from.
—	

Returns

`xQueueMessage` The next message in the queue. If the queue is empty or the queue parameter is invalid, `xQueuePeek()` will return null.

Warning

The memory allocated by `xQueuePeek()` must be freed by `xMemFree()`.

4.2.5.14 xQueueReceive() `xQueueMessage xQueueReceive (` `xQueue queue_)`

The `xQueueReceive()` system call will return the next message in the message queue and drop it from the message queue.

See also

[xQueueMessage](#)
[xMemFree\(\)](#)

Parameters

<i>queue</i> ↔	The queue to return the next message from.
—	

Returns

[xQueueMessage](#) The message returned from the queue. If the queue is empty of the queue parameter is invalid, [xQueueReceive\(\)](#) will return null.

Warning

The memory allocated by [xQueueReceive\(\)](#) must be freed by [xMemFree\(\)](#).

4.2.5.15 xQueueSend() [xBase](#) xQueueSend (
[xQueue](#) *queue_*,
[xBase](#) *messageBytes_*,
const char * *messageValue_*)

The [xQueueSend\(\)](#) system call will send a message using the specified message queue. The size of the message value is passed in the message bytes parameter. The maximum message value size in bytes is dependent on the CONFIG_MESSAGE_VALUE_BYTES setting.

See also

[CONFIG_MESSAGE_VALUE_BYTES](#)
[xQueuePeek\(\)](#)
[xQueueReceive\(\)](#)

Parameters

<i>queue_</i>	The queue to send the message to.
<i>message</i> ↔ <i>Bytes_</i>	The number of bytes contained in the message value. The number of bytes must be greater than zero and less than or equal to the setting CONFIG_MESSAGE_VALUE_BYTES.
<i>message</i> ↔ <i>Value_</i>	The message value. If the message value is greater than defined in CONFIG_MESSAGE_VALUE_BYTES, only the number of bytes defined in CONFIG_MESSAGE_VALUE_BYTES will be copied into the message value. The message value is NOT a null terminated string.

Returns

[xBase](#) [xQueueSend\(\)](#) returns RETURN_SUCCESS if the message was sent to the queue successfully. Otherwise RETURN_FAILURE if unsuccessful.

4.2.5.16 xSystemGetSystemInfo() `xSystemInfo xSystemGetSystemInfo (`
`void)`

Returns

`xSystemInfo` The system info is returned if successful, otherwise null is returned if unsuccessful.

See also

[xSystemInfo](#)

[xMemFree\(\)](#)

Warning

The memory allocated by the [xSystemGetSystemInfo\(\)](#) must be freed with [xMemFree\(\)](#)

4.2.5.17 xSystemHalt() `void xSystemHalt (`
`void)`

The [xSystemHalt\(\)](#) system call will halt HeliOS. Once [xSystemHalt\(\)](#) is called, the system must be reset.

4.2.5.18 xTaskChangePeriod() `void xTaskChangePeriod (`
`xTask task_,`
`xTime timerPeriod_)`

The [xTaskChangePeriod\(\)](#) system call will change the period (microseconds) on the task timer for the specified task. The timer period must be greater than zero. To have any effect, the task must be in the waiting state set by calling [xTaskWait\(\)](#) on the task. Once the timer period is set and the task is in the waiting state, the task will be executed every `timerPeriod_` microseconds. Changing the period to zero will prevent the task from being executed even if it is in the waiting state unless it were to receive a direct to task notification.

See also

[xTaskWait\(\)](#)

[xTaskGetPeriod\(\)](#)

[xTaskResetTimer\(\)](#)

Parameters

<i>task_</i>	The task to change the timer period for.
<i>timer↔ Period_</i>	The timer period in microseconds.

4.2.5.19 xTaskCreate() `xTask xTaskCreate (`
`const char * name_,`
`void(*) (xTask, xTaskParm) callback_,`
`xTaskParm taskParameter_)`

The `xTaskCreate()` system call will create a new task. The task will be created with its state set to suspended. The `xTaskCreate()` and `xTaskDelete()` system calls cannot be called within a task. They MUST be called outside of the scope of the Helios scheduler.

Parameters

<i>name_</i>	The ASCII name of the task which can be used by <code>xTaskGetHandleByName()</code> to obtain the task pointer. The length of the name is depended on the <code>CONFIG_TASK_NAME_BYTES</code> . The task name is NOT a null terminated char string.
<i>callback_</i>	The callback pointer to the task main function. This is the function that will be invoked by the scheduler when a task is scheduled for execution.
<i>task↔ Parameter_</i>	A pointer to any type or structure that the end-user wants to pass into the task as a parameter. The task parameter is not required and may simply be set to null.

Returns

`xTask` A pointer to the newly created task.

See also

`xTask`
`xTaskParm`
`xTaskDelete()`
`xTaskState`
`CONFIG_TASK_NAME_BYTES`

Warning

`xTaskCreate()` MUST be called outside the scope of the Helios scheduler (i.e., not from a task's main). The task memory can only be freed by `xTaskDelete()`.

4.2.5.20 xTaskDelete() `void xTaskDelete (`
`xTask task_)`

The `xTaskDelete()` system call will delete a task. The `xTaskCreate()` and `xTaskDelete()` system calls cannot be called within a task. They MUST be called outside of the scope of the Helios scheduler.

Parameters

<i>task↔ _</i>	A pointer to the task to be deleted.
--------------------	--------------------------------------

Warning

[xTaskDelete\(\)](#) MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main).

4.2.5.21 [xTaskGetAllRunTimeStats\(\)](#) [xTaskRunTimeStats](#) [xTaskGetAllRunTimeStats](#) ([xBase](#) * *tasks_*)

The [xTaskGetAllRunTimeStats\(\)](#) system call will return the runtime statistics for all of the tasks regardless of their state. The [xTaskGetAllRunTimeStats\(\)](#) system call returns the [xTaskRunTimeStats](#) type. An [xBase](#) variable must be passed by reference to [xTaskGetAllRunTimeStats\(\)](#) which will be updated by [xTaskGetAllRunTimeStats\(\)](#) to contain the number of tasks so the end-user can iterate through the tasks. The [xTaskRunTimeStats](#) memory must be freed by [xMemFree\(\)](#) after it is no longer needed.

See also

[xTaskRunTimeStats](#)

[xMemFree\(\)](#)

Parameters

<i>tasks_</i> ↔ —	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no tasks currently exist, this variable will not be modified.
----------------------	---

Returns

[xTaskRunTimeStats](#) The runtime stats returned by [xTaskGetAllRunTimeStats\(\)](#). If there are currently no tasks then this will be null. This memory must be freed by [xMemFree\(\)](#).

Warning

The memory allocated by [xTaskGetAllRunTimeStats\(\)](#) must be freed by [xMemFree\(\)](#).

4.2.5.22 [xTaskGetAllTaskInfo\(\)](#) [xTaskInfo](#) * [xTaskGetAllTaskInfo](#) ([xBase](#) * *tasks_*)

The [xTaskGetAllTaskInfo\(\)](#) system call returns the [xTaskInfo](#) structure containing the details of ALL tasks including their identifier, name, state and runtime statistics.

See also

[xTaskInfo](#)

Parameters

<i>tasks_</i> ↔ —	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no tasks currently exist, this variable will not be modified.
----------------------	---

Returns

xTaskInfo The xTaskInfo structure containing the tasks details. [xTaskGetAllTaskInfo\(\)](#) returns null if there no tasks or if a consistency issue is detected.

Warning

The memory allocated by [xTaskGetAllTaskInfo\(\)](#) must be freed by [xMemFree\(\)](#).

4.2.5.23 xTaskGetHandleById() `xTask xTaskGetHandleById (xBase id_)`

The [xTaskGetHandleById\(\)](#) system call will return a pointer to the task handle specified by its identifier.

See also

[xBase](#)

Parameters

<code>id_↔</code> <code>_↔</code>	The identifier of the task to return the handle pointer for.
--------------------------------------	--

Returns

xTask A pointer to the task handle. [xTaskGetHandleById\(\)](#) returns null if the the task identifier cannot be found.

4.2.5.24 xTaskGetHandleByName() `xTask xTaskGetHandleByName (const char * name_)`

The [xTaskGetHandleByName\(\)](#) system call will return the task handle pointer to the task specified by its ASCII name. The length of the task name is dependent on the CONFIG_TASK_NAME_BYTES setting. The name is compared byte-for-byte so the name is case sensitive.

See also

[CONFIG_TASK_NAME_BYTES](#)

Parameters

<code>name_↔</code> <code>_</code>	The ASCII name of the task to return the handle pointer for. The task name is NOT a null terminated string.
---------------------------------------	---

Returns

xTask A pointer to the task handle. [xTaskGetHandleByName\(\)](#) returns null if the name cannot be found.

4.2.5.25 xTaskGetId() [xBase](#) xTaskGetId (
 [xTask](#) task_)

The [xTaskGetId\(\)](#) system call returns the task identifier for the task.

Parameters

<i>task</i> ↔ —	The task to return the identifier of.
--------------------	---------------------------------------

Returns

xBase The identifier of the task. If the task cannot be found, [xTaskGetId\(\)](#) returns zero (all tasks identifiers are 1 or greater).

4.2.5.26 xTaskGetName() [char *](#) xTaskGetName (
 [xTask](#) task_)

The [xTaskGetName\(\)](#) system call returns the ASCII name of the task. The size of the task is dependent on the setting CONFIG_TASK_NAME_BYTES. The task name is NOT a null terminated char string. The memory allocated for the char array must be freed by [xMemFree\(\)](#) when no longer needed.

See also

[CONFIG_TASK_NAME_BYTES](#)
[xMemFree\(\)](#)

Parameters

<i>task</i> ↔ —	The task to return the name of.
--------------------	---------------------------------

Returns

char* A pointer to the char array containing the ASCII name of the task. The task name is NOT a null terminated char string. [xTaskGetName\(\)](#) will return null if the task cannot be found.

Warning

The memory allocated by [xTaskGetName\(\)](#) must be free by [xMemFree\(\)](#).

4.2.5.27 xTaskGetNumberOfTasks() `xBase` `xTaskGetNumberOfTasks` (
`void`)

The `xTaskGetNumberOfTasks()` system call returns the current number of tasks regardless of their state.

Returns

`xBase` The number of tasks.

4.2.5.28 xTaskGetPeriod() `xTime` `xTaskGetPeriod` (
`xTask` `task_`)

The `xTaskGetPeriod()` will return the period for the timer for the specified task. See `xTaskChangePeriod()` for more information on how the task timer works.

See also

[xTaskWait\(\)](#)
[xTaskChangePeriod\(\)](#)
[xTaskResetTimer\(\)](#)

Parameters

<code>task_↔</code>	The task to return the timer period for.
—	

Returns

`xTime` The timer period in microseconds. `xTaskGetPeriod()` will return zero if the timer period is zero or if the task could not be found.

4.2.5.29 xTaskGetSchedulerState() `xSchedulerState` `xTaskGetSchedulerState` (
`void`)

The `xTaskGetSchedulerState()` system call will return the state of the scheduler. The state of the scheduler can only be changed using `xTaskSuspendAll()` and `xTaskResumeAll()`.

See also

[xSchedulerState](#)
[xTaskSuspendAll\(\)](#)
[xTaskResumeAll\(\)](#)

Returns

`xSchedulerState` The state of the scheduler.

4.2.5.30 xTaskGetTaskInfo() `xTaskInfo` xTaskGetTaskInfo (
 `xTask` *task_*)

The `xTaskGetTaskInfo()` system call returns the `xTaskInfo` structure containing the details of the task including its identifier, name, state and runtime statistics.

See also

[xTaskInfo](#)

Parameters

<i>task_</i> ↔	The task to return the details of.
—	

Returns

`xTaskInfo` The `xTaskInfo` structure containing the task details. `xTaskGetTaskInfo()` returns null if the task cannot be found.

Warning

The memory allocated by `xTaskGetTaskInfo()` must be freed by `xMemFree()`.

4.2.5.31 xTaskGetTaskRunTimeStats() `xTaskRunTimeStats` xTaskGetTaskRunTimeStats (
 `xTask` *task_*)

The `xTaskGetTaskRunTimeStats()` system call returns the task runtime statistics for one task. The `xTaskGetTaskRunTimeStats()` system call returns the `xTaskRunTimeStats` type. The memory must be freed by calling `xMemFree()` after it is no longer needed.

See also

[xTaskRunTimeStats](#)

[xMemFree\(\)](#)

Parameters

<i>task_</i> ↔	The task to get the runtime statistics for.
—	

Returns

`xTaskRunTimeStats` The runtime stats returned by `xTaskGetTaskRunTimeStats()`. `xTaskGetTaskRunTimeStats()` will return null if the task cannot be found.

Warning

The memory allocated by `xTaskGetTaskRunTimeStats()` must be freed by `xMemFree()`.

4.2.5.32 xTaskGetTaskState() `xTaskState` `xTaskGetTaskState` (
`xTask` `task_`)

The `xTaskGetTaskState()` system call will return the state of the task.

See also

`xTaskState`

Parameters

<code>task_↔</code>	The task to return the state of.
—	

Returns

`xTaskState` The `xTaskState` of the task. If the task cannot be found, `xTaskGetTaskState()` will return null.

4.2.5.33 xTaskNotificationIsWaiting() `xBase` `xTaskNotificationIsWaiting` (
`xTask` `task_`)

The `xTaskNotificationIsWaiting()` system call will return true or false depending on whether there is a direct to task notification waiting for the task.

Parameters

<code>task_↔</code>	The task to check for a waiting task notification.
—	

Returns

`xBase` Returns true if there is a task notification. False if there is no notification or if the task could not be found.

4.2.5.34 xTaskNotifyGive() `Base_t` `xTaskNotifyGive` (
`xTask` `task_`,
`xBase` `notificationBytes_`,
`const char *` `notificationValue_`)

The `xTaskNotifyGive()` system call will give a direct to task notification to the specified task. The task notification bytes is the number of bytes contained in the notification value. The number of notification bytes must be between one and the `CONFIG_NOTIFICATION_VALUE_BYTES` setting. The notification value must contain a pointer to a char array containing the notification value. If the task already has a waiting task notification, `xTaskNotifyGive()` will NOT overwrite the waiting task notification. `xTaskNotifyGive()` will return true if the direct to task notification was successfully given.

See also

`CONFIG_NOTIFICATION_VALUE_BYTES`
`xTaskNotifyTake()`

Parameters

<i>task_</i>	The task to send the task notification to.
<i>notification↔ Bytes_</i>	The number of bytes contained in the notification value. The number must be between one and the <code>CONFIG_NOTIFICATION_VALUE_BYTES</code> setting.
<i>notification↔ Value_</i>	A char array containing the notification value. The notification value is NOT a null terminated string.

Returns

xBase RETURN_SUCCESS if the direct to task notification was successfully given, RETURN_FAILURE if not.

4.2.5.35 xTaskNotifyStateClear() `void xTaskNotifyStateClear (`
`xTask task_)`

The `xTaskNotifyStateClear()` system call will clear a waiting direct to task notification if one exists without returning the notification.

Parameters

<i>task↔ _</i>	The task to clear the notification for.
--------------------	---

4.2.5.36 xTaskNotifyTake() `xTaskNotification xTaskNotifyTake (`
`xTask task_)`

The `xTaskNotifyTake()` system call will return the waiting direct to task notification if there is one. The `xTaskNotifyTake()` system call will return an `xTaskNotification` structure containing the notification bytes and its value. The memory allocated by `xTaskNotifyTake()` must be freed by `xMemFree()`.

See also

`xTaskNotification`
`xTaskNotifyGive()`
`xMemFree()`
`CONFIG_NOTIFICATION_VALUE_BYTES`

Parameters

<i>task</i> ↔	The task to return a waiting task notification.
—	

Returns

`xTaskNotification` The `xTaskNotification` structure containing the notification bytes and value. [xTaskNotifyTake\(\)](#) will return null if no waiting task notification exists or if the task cannot be found.

Warning

The memory allocated by [xTaskNotifyTake\(\)](#) must be freed by [xMemFree\(\)](#).

4.2.5.37 xTaskResetTimer() `void xTaskResetTimer (`
`xTask task_)`

The [xTaskResetTimer\(\)](#) system call will reset the task timer. [xTaskResetTimer\(\)](#) does not change the timer period or the task state when called. See [xTaskChangePeriod\(\)](#) for more details on task timers.

See also

[xTaskWait\(\)](#)
[xTaskChangePeriod\(\)](#)
[xTaskGetPeriod\(\)](#)

Parameters

<i>task</i> ↔	The task to reset the task timer for.
—	

4.2.5.38 xTaskResume() `void xTaskResume (`
`xTask task_)`

The [xTaskResume\(\)](#) system call will resume a suspended task. Tasks are suspended on creation so either [xTaskResume\(\)](#) or [xTaskWait\(\)](#) must be called to place the task in a state that the scheduler will execute.

See also

[xTaskState](#)
[xTaskSuspend\(\)](#)
[xTaskWait\(\)](#)

Parameters

<i>task</i> ↔	The task to set its state to running.
—	

4.2.5.39 xTaskResumeAll() `void xTaskResumeAll (`
`void)`

The [xTaskResumeAll\(\)](#) system call will set the scheduler state to running so the next call to [xTaskStartScheduler\(\)](#) will resume execute of all tasks. The state of each task is not altered by [xTaskSuspendAll\(\)](#) or [xTaskResumeAll\(\)](#).

See also

[xTaskSuspendAll\(\)](#)

4.2.5.40 xTaskStartScheduler() `void xTaskStartScheduler (`
`void)`

The [xTaskStartScheduler\(\)](#) system call passes control to the HeliOS scheduler. This system call will not return until [xTaskSuspendAll\(\)](#) is called. If [xTaskSuspendAll\(\)](#) is called, [xTaskResumeAll\(\)](#) must be called before [xTaskStartScheduler\(\)](#) can be called again to continue executing tasks.

4.2.5.41 xTaskSuspend() `void xTaskSuspend (`
`xTask task_)`

The [xTaskSuspend\(\)](#) system call will suspend a task. A task that has been suspended will not be executed by the scheduler until [xTaskResume\(\)](#) or [xTaskWait\(\)](#) is called.

See also

[xTaskState](#)

[xTaskResume\(\)](#)

[xTaskWait\(\)](#)

Parameters

<i>task</i> ↔	The task to suspend.
—	

4.2.5.42 xTaskSuspendAll() `void xTaskSuspendAll (`
`void)`

The [xTaskSuspendAll\(\)](#) system call will set the scheduler state to suspended so the scheduler will stop and return. The state of each task is not altered by [xTaskSuspendAll\(\)](#) or [xTaskResumeAll\(\)](#).

See also

[xTaskResumeAll\(\)](#)

4.2.5.43 xTaskWait() `void xTaskWait (`
`xTask task_)`

The [xTaskWait\(\)](#) system call will place a task in the waiting state. A task must be in the waiting state for event driven multitasking with either direct to task notifications OR setting the period on the task timer with [xTaskChangePeriod\(\)](#). A task in the waiting state will not be executed by the scheduler until an event has occurred.

See also

[xTaskState](#)

[xTaskResume\(\)](#)

[xTaskSuspend\(\)](#)

Parameters

<i>task</i> ↔	The task to place in the waiting state.
—	

4.2.5.44 xTimerChangePeriod() `void xTimerChangePeriod (`
`xTimer timer_,`
`xTime timerPeriod_)`

The [xTimerChangePeriod\(\)](#) system call will change the period of the specified timer. The timer period is measured in microseconds. If the timer period is zero, the [xTimerHasTimerExpired\(\)](#) system call will always return false.

See also

[xTimerHasTimerExpired\(\)](#)

Parameters

<i>timer_</i>	The timer to change the period for.
<i>timer</i> ↔ <i>Period_</i>	The timer period in is microseconds. Timer period must be zero or greater.

4.2.5.45 xTimerCreate() `xTimer xTimerCreate (`

```
xTime timerPeriod_ )
```

The `xTimerCreate()` system call will create a new timer. Timers differ from task timers in that they do not create events that effect the scheduling of a task. Timers can be used by tasks to initiate various task activities based on a specified time period represented in microseconds. The memory allocated by `xTimerCreate()` must be freed by `xTimerDelete()`. Unlike tasks, timers may be created and deleted within tasks.

See also

`xTimer`

`xTimerDelete()`

Parameters

<i>timer</i> ↔ <i>Period_</i>	The number of microseconds before the timer expires.
----------------------------------	--

Returns

`xTimer` The newly created timer. If the timer period parameter is less than zero or `xTimerCreate()` was unable to allocate the required memory, `xTimerCreate()` will return null.

Warning

The timer memory can only be freed by `xTimerDelete()`.

4.2.5.46 xTimerDelete() `void xTimerDelete (`

```
xTimer timer_ )
```

The `xTimerDelete()` system call will delete a timer. For more information on timers see the `xTaskTimerCreate()` system call.

See also

`xTimerCreate()`

Parameters

<i>timer</i> ↔ —	The timer to be deleted.
---------------------	--------------------------

4.2.5.47 xTimerGetPeriod() `xTime xTimerGetPeriod (`

```
xTimer timer_ )
```

The `xTimerGetPeriod()` system call will return the current timer period for the specified timer.

Parameters

<i>timer</i> ↔	The timer to get the timer period for.
—	

Returns

xTime The timer period. If the timer cannot be found, [xTimerGetPeriod\(\)](#) will return zero.

4.2.5.48 xTimerHasTimerExpired() `xBase xTimerHasTimerExpired (`
`xTimer timer_)`

The [xTimerHasTimerExpired\(\)](#) system call will return true or false dependent on whether the timer period for the specified timer has elapsed. [xTimerHasTimerExpired\(\)](#) will NOT reset the timer. Timers will not automatically reset. Timers MUST be reset with [xTimerReset\(\)](#).

See also

[xTimerReset\(\)](#)

Parameters

<i>timer</i> ↔	The timer to determine if the period has expired.
—	

Returns

xBase True if the timer has expired, false if the timer has not expired or could not be found.

4.2.5.49 xTimerIsTimerActive() `xBase xTimerIsTimerActive (`
`xTimer timer_)`

The [xTimerIsTimerActive\(\)](#) system call will return true if the timer has been started with [xTimerStart\(\)](#).

See also

[xTimerStart\(\)](#)

Parameters

<i>timer</i> ↔	The timer to check if active.
—	

Returns

xBase True if active, false if not active or if the timer could not be found.

4.2.5.50 xTimerReset() `void xTimerReset (`
 `xTimer timer_)`

The `xTimerReset()` system call will reset the start time of the timer to zero.

Parameters

<i>timer</i> ↔	The timer to be reset.
—	

4.2.5.51 xTimerStart() `void xTimerStart (`
 `xTimer timer_)`

The `xTimerStart()` system call will place the timer in the running (active) state. Neither `xTimerStart()` nor `xTimerStop()` will reset the timer. Timers can only be reset with `xTimerReset()`.

See also

[xTimerStop\(\)](#)
[xTimerReset\(\)](#)

Parameters

<i>timer</i> ↔	The timer to be started.
—	

4.2.5.52 xTimerStop() `void xTimerStop (`
 `xTimer timer_)`

See also

[xTimerStart\(\)](#)
[xTimerReset\(\)](#)

Parameters

<i>timer</i> ↔	The timer to be stopped.
—	

Index

Base_t

HeliOS.h, [16](#)

config.h, [8](#)

CONFIG_ENABLE_ARDUINO_CPP_INTERFACE, [9](#)

CONFIG_ENABLE_SYSTEM_ASSERT, [9](#)

CONFIG_HEAP_BLOCK_SIZE, [9](#)

CONFIG_HEAP_SIZE_IN_BLOCKS, [9](#)

CONFIG_MESSAGE_VALUE_BYTES, [10](#)

CONFIG_NOTIFICATION_VALUE_BYTES, [10](#)

CONFIG_QUEUE_MINIMUM_LIMIT, [10](#)

CONFIG_SYSTEM_ASSERT_BEHAVIOR, [11](#)

CONFIG_TASK_NAME_BYTES, [11](#)

CONFIG_ENABLE_ARDUINO_CPP_INTERFACE

config.h, [9](#)

CONFIG_ENABLE_SYSTEM_ASSERT

config.h, [9](#)

CONFIG_HEAP_BLOCK_SIZE

config.h, [9](#)

CONFIG_HEAP_SIZE_IN_BLOCKS

config.h, [9](#)

CONFIG_MESSAGE_VALUE_BYTES

config.h, [10](#)

CONFIG_NOTIFICATION_VALUE_BYTES

config.h, [10](#)

CONFIG_QUEUE_MINIMUM_LIMIT

config.h, [10](#)

CONFIG_SYSTEM_ASSERT_BEHAVIOR

config.h, [11](#)

CONFIG_TASK_NAME_BYTES

config.h, [11](#)

DEREF_TASKPARAM

HeliOS.h, [16](#)

HeliOS.h, [11](#)

Base_t, [16](#)

DEREF_TASKPARAM, [16](#)

Queue_t, [16](#)

SchedulerState_t, [22](#)

SchedulerStateError, [22](#)

SchedulerStateRunning, [22](#)

SchedulerStateSuspended, [22](#)

SystemAssert, [23](#)

Task_t, [16](#)

TaskParm_t, [17](#)

TaskState_t, [22](#)

TaskStateError, [23](#)

TaskStateRunning, [23](#)

TaskStateSuspended, [23](#)

TaskStateWaiting, [23](#)

Time_t, [17](#)

Timer_t, [17](#)

xBase, [18](#)

xMemAlloc, [23](#)

xMemFree, [24](#)

xMemGetSize, [25](#)

xMemGetUsed, [25](#)

xQueue, [18](#)

xQueueCreate, [25](#)

xQueueDelete, [26](#)

xQueueDropMessage, [26](#)

xQueueGetLength, [26](#)

xQueueIsQueueEmpty, [27](#)

xQueueIsQueueFull, [27](#)

xQueueMessage, [18](#)

xQueueMessagesWaiting, [27](#)

xQueuePeek, [28](#)

xQueueReceive, [28](#)

xQueueSend, [29](#)

xSchedulerState, [19](#)

xSystemGetSystemInfo, [30](#)

xSystemHalt, [30](#)

xSystemInfo, [19](#)

xTask, [19](#)

xTaskChangePeriod, [30](#)

xTaskCreate, [30](#)

xTaskDelete, [31](#)

xTaskGetAllRunTimeStats, [32](#)

xTaskGetAllTaskInfo, [32](#)

xTaskGetHandleById, [33](#)

xTaskGetHandleByName, [33](#)

xTaskGetId, [34](#)

xTaskGetName, [34](#)

xTaskGetNumberOfTasks, [34](#)

xTaskGetPeriod, [35](#)

xTaskGetSchedulerState, [35](#)

xTaskGetTaskInfo, [35](#)

xTaskGetTaskRunTimeStats, [36](#)

xTaskGetTaskState, [37](#)

xTaskInfo, [20](#)

xTaskNotification, [20](#)

xTaskNotificationIsWaiting, [37](#)

xTaskNotifyGive, [37](#)

xTaskNotifyStateClear, [38](#)

xTaskNotifyTake, [38](#)

xTaskParm, [20](#)

xTaskResetTimer, [39](#)

xTaskResume, [39](#)

xTaskResumeAll, [40](#)

xTaskRunTimeStats, [21](#)

xTaskStartScheduler, [40](#)

xTaskState, [21](#)

xTaskSuspend, [40](#)

xTaskSuspendAll, [40](#)

xTaskWait, [41](#)

xTime, [21](#)

xTimer, [22](#)

xTimerChangePeriod, [41](#)

xTimerCreate, [41](#)

- xTimerDelete, 42
 - xTimerGetPeriod, 42
 - xTimerHasTimerExpired, 43
 - xTimerIsTimerActive, 43
 - xTimerReset, 44
 - xTimerStart, 44
 - xTimerStop, 44
- id
 - TaskInfo_t, 5
 - TaskRunTimeStats_t, 7
- lastRunTime
 - TaskInfo_t, 5
 - TaskRunTimeStats_t, 7
- majorVersion
 - SystemInfo_t, 4
- messageBytes
 - QueueMessage_t, 3
- messageValue
 - QueueMessage_t, 3
- minorVersion
 - SystemInfo_t, 4
- name
 - TaskInfo_t, 5
- notificationBytes
 - TaskNotification_t, 6
- notificationValue
 - TaskNotification_t, 6
- numberOfTasks
 - SystemInfo_t, 4
- patchVersion
 - SystemInfo_t, 4
- productName
 - SystemInfo_t, 4
- Queue_t
 - HeliOS.h, 16
- QueueMessage_t, 2
 - messageBytes, 3
 - messageValue, 3
- SchedulerState_t
 - HeliOS.h, 22
- SchedulerStateError
 - HeliOS.h, 22
- SchedulerStateRunning
 - HeliOS.h, 22
- SchedulerStateSuspended
 - HeliOS.h, 22
- state
 - TaskInfo_t, 5
- SystemAssert
 - HeliOS.h, 23
- SystemInfo_t, 3
 - majorVersion, 4
 - minorVersion, 4
 - numberOfTasks, 4
 - patchVersion, 4
 - productName, 4
- Task_t
 - HeliOS.h, 16
- TaskInfo_t, 4
 - id, 5
 - lastRunTime, 5
 - name, 5
 - state, 5
 - totalRunTime, 5
- TaskNotification_t, 6
 - notificationBytes, 6
 - notificationValue, 6
- TaskParm_t
 - HeliOS.h, 17
- TaskRunTimeStats_t, 7
 - id, 7
 - lastRunTime, 7
 - totalRunTime, 7
- TaskState_t
 - HeliOS.h, 22
- TaskStateError
 - HeliOS.h, 23
- TaskStateRunning
 - HeliOS.h, 23
- TaskStateSuspended
 - HeliOS.h, 23
- TaskStateWaiting
 - HeliOS.h, 23
- Time_t
 - HeliOS.h, 17
- Timer_t
 - HeliOS.h, 17
- totalRunTime
 - TaskInfo_t, 5
 - TaskRunTimeStats_t, 7
- xBase
 - HeliOS.h, 18
- xMemAlloc
 - HeliOS.h, 23
- xMemFree
 - HeliOS.h, 24
- xMemGetSize
 - HeliOS.h, 25
- xMemGetUsed
 - HeliOS.h, 25
- xQueue
 - HeliOS.h, 18
- xQueueCreate
 - HeliOS.h, 25
- xQueueDelete
 - HeliOS.h, 26
- xQueueDropMessage
 - HeliOS.h, 26
- xQueueGetLength
 - HeliOS.h, 26

xQueueIsQueueEmpty
HeliOS.h, [27](#)

xQueueIsQueueFull
HeliOS.h, [27](#)

xQueueMessage
HeliOS.h, [18](#)

xQueueMessagesWaiting
HeliOS.h, [27](#)

xQueuePeek
HeliOS.h, [28](#)

xQueueReceive
HeliOS.h, [28](#)

xQueueSend
HeliOS.h, [29](#)

xSchedulerState
HeliOS.h, [19](#)

xSystemGetSystemInfo
HeliOS.h, [30](#)

xSystemHalt
HeliOS.h, [30](#)

xSystemInfo
HeliOS.h, [19](#)

xTask
HeliOS.h, [19](#)

xTaskChangePeriod
HeliOS.h, [30](#)

xTaskCreate
HeliOS.h, [30](#)

xTaskDelete
HeliOS.h, [31](#)

xTaskGetAllRunTimeStats
HeliOS.h, [32](#)

xTaskGetAllTaskInfo
HeliOS.h, [32](#)

xTaskGetHandleById
HeliOS.h, [33](#)

xTaskGetHandleByName
HeliOS.h, [33](#)

xTaskGetId
HeliOS.h, [34](#)

xTaskGetName
HeliOS.h, [34](#)

xTaskGetNumberOfTasks
HeliOS.h, [34](#)

xTaskGetPeriod
HeliOS.h, [35](#)

xTaskGetSchedulerState
HeliOS.h, [35](#)

xTaskGetTaskInfo
HeliOS.h, [35](#)

xTaskGetTaskRunTimeStats
HeliOS.h, [36](#)

xTaskGetTaskState
HeliOS.h, [37](#)

xTaskInfo
HeliOS.h, [20](#)

xTaskNotification
HeliOS.h, [20](#)

xTaskNotificationIsWaiting
HeliOS.h, [37](#)

xTaskNotifyGive
HeliOS.h, [37](#)

xTaskNotifyStateClear
HeliOS.h, [38](#)

xTaskNotifyTake
HeliOS.h, [38](#)

xTaskParm
HeliOS.h, [20](#)

xTaskResetTimer
HeliOS.h, [39](#)

xTaskResume
HeliOS.h, [39](#)

xTaskResumeAll
HeliOS.h, [40](#)

xTaskRunTimeStats
HeliOS.h, [21](#)

xTaskStartScheduler
HeliOS.h, [40](#)

xTaskState
HeliOS.h, [21](#)

xTaskSuspend
HeliOS.h, [40](#)

xTaskSuspendAll
HeliOS.h, [40](#)

xTaskWait
HeliOS.h, [41](#)

xTime
HeliOS.h, [21](#)

xTimer
HeliOS.h, [22](#)

xTimerChangePeriod
HeliOS.h, [41](#)

xTimerCreate
HeliOS.h, [41](#)

xTimerDelete
HeliOS.h, [42](#)

xTimerGetPeriod
HeliOS.h, [42](#)

xTimerHasTimerExpired
HeliOS.h, [43](#)

xTimerIsTimerActive
HeliOS.h, [43](#)

xTimerReset
HeliOS.h, [44](#)

xTimerStart
HeliOS.h, [44](#)

xTimerStop
HeliOS.h, [44](#)